

ST304-DSR1K-T-HL HIGHLIGHT LIST FUNCTIONS

OVERVIEW

The HIGHLIGHT feature lets you create a sequence of cues that can be played out as a highlight reel. Ten different reels with twenty elements each can be created. The reels can be edited by adding, deleting, or inserting elements as long as the list is not in play mode. Only the cue points from the current channel (player/recorder pair) may be added to the playlist. The playlists and their elements cannot be shared between channels.

FUNCTIONS

The following playlist functions are available:

- 1) Select a Playlist
- 2) Cue the playlist to the selected element
- 3) Append an element to the end of the playlist.
- 4) Insert an element before the selected element in the playlist.
- 5) Delete an element from the playlist.
- 6) Play the playlist at 100% play speed.
- 7) Play the playlist at a speed less than 100% play speed.
- 8) Pause, Restart, Jog and Shuttle through the list.
- 9) Clear the playlist.
- 10) Loop a clip or a playlist. (Future function)

LIMITATIONS

The system has the following limitations:

- 1) It can only control DSR-DR100 Ver2.0 software and above.
- 2) The playlist cannot be edited while it is playing
- 3) Separate Slo-motion speeds cannot be assigned to the playlists' elements.
- 4) The IN and OUT points of the elements of the playlist cannot be edited while in PL mode. The Cue (element) IN and OUT points can be edited and then reload the list.